

**Saeco**  
**International Group S.p.A.**

Via Torretta, 240  
I-40041 Gaggio Montano, Bologna  
Tel: + 39 0534 771111

Fax: + 39 0534 31025  
[www.saeco.com](http://www.saeco.com)

The manufacturer reserves the right to change the features of the product without prior notice.

Le producteur se réserve le droit d'apporter toutes modifications sans préavis.

© Saeco International Group S.p.A.

# Primea *Cappuccino*

## Touch Plus



### **Operation and maintenance manual**

Before using the machine, please read the attached operating instructions.

Carefully read the safety rules

### **Mode d'emploi**

Veuillez lire attentivement le mode d'emploi  
(notamment les consignes de sécurité) avant d'utiliser l'appareil.



## FOR HOUSEHOLD USE ONLY

 **Saeco**

# IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- 1 Read all instructions and information in this instruction book and any other literature included in this carton referring to this product before operating or using this appliance.
- 2 Do not touch hot surfaces. Use handles or knobs.
- 3 To protect against fire, electric shock and personal injury do not immerse cord, plugs or appliance in water or other liquid.
- 4 Close supervision is necessary when any appliance is used by or near children.
- 5 Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- 6 Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any way. Return appliance to the nearest authorized service centre for examination, repair or adjustment.
- 7 The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock or personal injury.
- 8 Do not use outdoors.
- 9 Do not let cord hang over edge of table or counter, or touch hot surfaces.
- 10 Do not place on or near a hot gas or electric burner, or in a heated oven.
- 11 Always turn appliance **"OFF"**, then plug cord into the wall outlet. To disconnect, turn switch to **"OFF"**, then remove plug from wall outlet.
- 12 Do not use appliance for other than intended household use.
- 13 Use extreme caution when using hot steam.

## SAVE THESE INSTRUCTIONS

# CAUTION

This appliance is for household use. Any servicing, other than cleaning and user maintenance, should be performed by an authorized service centre. Do not immerse base in water. To reduce the risk of fire or electric shock, do not disassemble the base. There are no user serviceable parts inside. Repair should be done by authorized service personnel only.

- 1 Check voltage to be sure that the voltage indicated on the nameplate corresponds with your voltage.
- 2 Never use warm or hot water to fill the water tank. Use cold water only.
- 3 Keep your hands and the cord away from hot parts of the appliance during operation.
- 4 Never clean with scouring powders or hard implements. Simply use a soft cloth dampened with water.
- 5 For optimal taste of your coffee, use purified or bottled water. Periodic descaling is still recommended every 2-3 months.

## INSTRUCTIONS FOR THE POWER SUPPLY CORD

- A A short power-supply cord is provided to reduce risks of getting tangled up or tripping over a longer cord.
- B Longer extension cords are available and may be used if care is exercised in their use.
- C If a long extension cord is used:
  - 1 the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance.
  - 2 if the appliance is of the grounded type, the extension cord should be a grounding type
  - 3 the cord does not hang from the table to avoid the risk of getting caught up in it.

GENERAL INFORMATION.....	3
MACHINE.....	4
ACCESSORIES.....	4
INSTALLATION.....	5
STARTING THE MACHINE.....	5
MANUAL PRIMING OF THE WATER CIRCUIT.....	6
SETTING THE LANGUAGE AND THE CLOCK.....	6
"AQUA PRIMA" FILTER.....	7
DISPLAY.....	8
CHOOSE COFFEE AROMA.....	8
ADJUSTMENTS.....	9
COFFEE INTENSITY.....	9
ADJUSTING THE HEIGHT OF THE DRIP TRAY.....	9
FILLING THE MILK CONTAINER.....	9
PRODUCT DISPENSING.....	10
ESPRESSO / COFFEE / LONG COFFEE.....	10
DISPENSING BEVERAGES WITH GROUND COFFEE.....	11
HOT WATER DISPENSING.....	12
LATTE MACCHIATO.....	12
DISPENSING HOT MILK.....	13
ESPRESSO MACCHIATO.....	14
CAPPUCCINO.....	14
BEVERAGE PROGRAMMING.....	15
BEVERAGE PROGRAMMING MENU.....	15
ESPRESSO / COFFEE / LONG COFFEE PROGRAM.....	15
PROGRAMMING MILK BEVERAGES.....	16
MACHINE SETTINGS.....	18
PROGRAMMING THE MACHINE.....	18
"LANGUAGE" MENU.....	19
"CUP ILLUMINATION" MENU.....	19
"AQUA PRIMA FILTER" MENU.....	19
"WATER HARDNESS" MENU.....	20
"RINSE" MENU.....	20
"CUP WARMING PLATE" MENU.....	21
"ACCOUSTIC TONES AND ALARMS" MENU.....	21
"DISPLAY" MENU.....	21
BEVERAGE SETTINGS.....	22
ADJUSTMENT OF THE COFFEE BREW TEMPERATURE.....	22
"AROMA" ADJUSTMENT FOR COFFEE BREWING.....	23
"PREBREWING" ADJUSTMENT (ONLY COFFEE BEVERAGES).....	23
ADDITIONAL FUNCTIONS.....	24
"COFFEE IN THE WORLD" FUNCTION.....	24
"DEMO" MODE.....	26
PRODUCT COUNTER FUNCTION.....	26
MAINTENANCE.....	27
MILK CIRCUIT RINSE CYCLE.....	27
MILK CIRCUIT WASH CYCLE.....	28
COFFEE CIRCUIT CLEANING CYCLE (BREW GROUP WASH CYCLE).....	30
BLOCK DISPLAY.....	30
DESCALING.....	31
CLOCK SETTINGS.....	33
TIME SETTING.....	33
CLOCK SETTINGS.....	34
ENERGY SAVING SETTINGS.....	36
SPECIAL.....	37
FACTORY SETTINGS.....	37
CLEANING AND MAINTENANCE.....	38
GENERAL MACHINE CLEANING.....	38
CLEANING THE BREW GROUP.....	39
GRINDER MAINTENANCE.....	40
MILK CONTAINER CLEANING.....	40
ERROR CODES.....	41
TECHNICAL DATA.....	42
SAFETY RULES.....	43

## GENERAL INFORMATION

---

**The coffee machine is intended for preparing espresso by using either coffee beans or ground coffee. It includes an automatic device for preparing milk products and a hot water dispenser. The machine is elegantly designed for domestic use and is not suitable for continuous heavy duty use of a professional kind.**

**Warning: no liability is assumed for any damage caused by:**

- Incorrect use not in accordance with the intended uses;
- Repairs not carried out by authorized customer service centers;
- Tampering with the power cord;
- Tampering with any part of the machine;
- The use of non-original spare parts and accessories;
- Failure to descale the machine or use at temperatures below 0°C.

**IN THESE CASES, THE WARRANTY IS NOT VALID.**



**A WARNING TRIANGLE DRAWS ATTENTION TO ALL THE INSTRUCTIONS THAT ARE IMPORTANT FOR USER SAFETY. PLEASE FOLLOW THESE INSTRUCTIONS CAREFULLY TO AVOID SERIOUS INJURY!**

## HOW TO USE THESE OPERATING INSTRUCTIONS

---

Keep these operating instructions in a safe place and make them available to anyone else who may use the coffee machine. For further information or if you experience problems not completely or sufficiently addressed in these instructions, please contact an Authorized Customer Service Center.

**KEEP THESE INSTRUCTIONS**



## ACCESSORIES



## STARTING THE MACHINE

Make sure that the main power button is not switched to the "ON" position.




Press the button on the coffee hopper to open the cover. Fill the hopper with coffee beans.



Close the cover pushing it down completely.



Remove the water tank. We recommend installing the "Aqua Prima" filter (see page 7).



Fill the tank with fresh drinking water. Do not exceed the "max" level indicated on the water tank. Once filled place the tank back into the machine.



Attach the female end of the power cord to the machine. Insert the male end into the power outlet.



Place a container beneath the hot water spout.



Press the main switch once to turn on the machine. The appliance automatically performs a diagnosis of its functions. This test is performed each time the machine is turned on.

The machine automatically primes the water circuit.

Water may not be dispensed into the glass.

The machine is now ready for use.

This should not be considered a malfunction.

**TO ASSESS WATER HARDNESS, SEE "WATER HARDNESS MENU" ON PAGE 23.**




## MANUAL PRIMING OF THE WATER CIRCUIT

Manually prime the water circuit only when the following display appears.

Note: first make sure that the water tank is full.



Position a container under the hot water spout (it is possible that water will not come out of the spout).




Press the display once and the machine will begin priming the water circuit.




When the prime circuit cycle is finished, remove the container. The machine is now ready for use.

## SETTING THE LANGUAGE AND THE CLOCK


These settings allow you to regulate the machine parameters to dispense coffee according to the typical parameters of the country where it is used. For this reason, the languages are also differentiated by location.




Press "programming menu".




Press "machine settings".




Press "language".



Select the desired language.



Return to the main menu. Press "timer"



See page 33 to adjust the clock.

## «AQUA PRIMA» FILTER

To improve the quality of the water used, install the "Aqua Prima" filter. After installation, go to the filter activation program (see programming). In this mode the machine advises the user when the filter must be replaced.



Remove the "Aqua Prima" filter from its packaging. Enter the date of the current month.



Insert the applicator on the filter.



Insert the filter in its place within the empty tank (see figure). Press down until it clicks into place. Remove the filter applicator.




Fill the tank with fresh water. Let the filter soak for 30 minutes. After 30 minutes discard the water in the tank and refill with fresh water.




Place a container beneath the hot water spout.




Press "programming menu".



Press "machine settings".



Press "water filter".




Press "activate filter".

The machine then activates the "Aqua Prima" filter. Wait for the cycle to finish automatically.

When the activation cycle ends, the machine proceeds to the choose product menu.

It is possible to change the type of display and choose between "icon format" and "text format"



- To get the desired beverage, press the corresponding symbol on the display. The machine automatically performs all the necessary operations.
- To make 2 cups, press the beverage symbol twice.



## CHOOSE COFFEE AROMA

The intensity of the color on the cup icon (only valid for coffee beverages) indicates the aroma, or quantity of coffee to be ground, for preparing the drink. The greater the quantity of coffee ground the stronger the coffee will taste.



When the machine is programmed to use pre-ground coffee or when a product is customized, the icon is displayed in a different way and/or accompanied by an asterisk (see section on "programming beverages".)



## COFFEE INTENSITY

The SBS system has been carefully designed to give your coffee the intense taste you desire. Simply turn the dial and you will notice that the coffee goes from mild intensity to strong intensity.

### SBS – SAECO BREWING SYSTEM

SBS adjusts the intensity of the brewed coffee, and can even be adjusted while brewing. Any adjustment has an immediate effect on the brewing coffee.



## ADJUSTING THE HEIGHT OF THE DRIP TRAY.

Adjust the drip tray before dispensing any products.



Height adjustable drip tray.

To raise the drip tray, press lightly on the lower part of the button. To lower the tray, press lightly on the upper part of the button; when the desired height is reached, release the button.

Note: There is a red floater in the drip tray. When it rises, the tray must be emptied and washed.

## FILLING THE MILK CONTAINER

Only the container with the cappuccinatore must be filled before preparing beverages with milk. Do not use milk after the best-before date. **(Important! Refer to the instructions for maintenance and cleaning of the cappuccinatore on page 40).**



Open the milk compartment and remove the container located within.



Remove the container cover and pour in the milk. Close the container and put it back in its appropriate place. Make sure to carefully close the compartment.

We recommend using the other supplied container to store any remaining milk in the refrigerator. Clean the circuits using only the container with the cappuccinatore.

**DISPENSING COFFEE, HOT WATER AND MILK CAN BE INTERRUPTED AT ANY TIME BY SELECTING THE "STOP ... DISPENSING" BUTTON.**



**THE DISPENSED MILK CAN REACH HIGH TEMPERATURES: THERE IS A DANGER OF SCALDING. DO NOT TOUCH IT WITH BARE HANDS.**

**THE MILK USED MUST HAVE BEEN PROPERLY PRESERVED.  
DO NOT USE IT AFTER THE EXPIRATION DATE ON THE PACKAGE.**


Check that all the containers are clean. To do this operation, follow the instructions in the "Cleaning and Maintenance" chapter (see page 38).

**WHEN YOU HAVE FINISHED PREPARING BEVERAGES CONTAINING MILK, PROCEED WITH CLEANING THE CONTAINER AND THE MACHINE'S CIRCUIT.**

To brew 2 cups, the machine dispenses half of the entered quantity and briefly interrupts dispensing in order to grind the second serving of coffee. Coffee dispensing is then restarted and completed. If a milk beverage has been chosen, the machine automatically dispenses the milk. If the first coffee is interrupted, the second will not be dispensed.

## ESPRESSO / COFFEE / LONG COFFEE

This procedure shows how to dispense an espresso. To dispense another type of coffee, press the appropriate icon. Use appropriate espresso or coffee cups so that the coffee will not overflow.



Choose the product and press the corresponding icon on the display: once for 1 cup and twice for 2 cups.



The machine begins grinding the quantity of coffee entered.



Begin dispensing the selected beverage.

The machine ends dispensing automatically according to the quantity determined by the manufacturer. It is possible to customize this quantity. See page 15.

If you wish to interrupt the dispensing cycle, press the " stop coffee dispensing" button.

## DISPENSING BEVERAGES WITH GROUND COFFEE

Pre-ground coffee must be poured into the appropriate compartment positioned next to the coffee bean hopper. Pour in only coffee ground for espresso machines and never coffee beans or instant coffee. (see the "Beverage programming" chapter on page 15).

**WARNING: PUT PRE-GROUND COFFEE IN THE COMPARTMENT ONLY WHEN YOU WISH TO DISPENSE THIS TYPE OF PRODUCT.**




**INSERT ONLY ONE SCOOP OF GROUND COFFEE AT A TIME. TWO CUPS OF COFFEE CANNOT BE DISPENSED AT THE SAME TIME.**

In the example given below, we chose to dispense a long coffee using pre-ground coffee. The customized choice of using pre-ground coffee is shown on the display with an asterisk next to the chosen beverage.



Press the appropriate button and the display will show:




A message reminding the user to pour ground coffee in the appropriate compartment.



Pour ground coffee into the pre-ground coffee compartment using the measuring scoop provided with the accessories.



Press the "go!" button to start dispensing.



Begins dispensing the selected beverage.


### Note:

- After 1 minute from when the message appears (2), if brewing has not started the machine will return to the main menu and dump any inserted coffee into the coffee dregs drawer.
- If no pre-ground coffee is poured into the compartment, only water will be dispensed.
- If 2 or more scoops of coffee are added, the machine will not dispense the product and the coffee in the compartment will be dumped into the coffee dregs drawer.


## HOT WATER DISPENSING



WHEN THE HOT WATER BEGINS TO DISPENSE, SHORT SPURTS OF HOT WATER MAY BE DISPENSED WHICH POSE A RISK OF SCALDING. THE HOT WATER SPOUT CAN REACH HIGH TEMPERATURES: AVOID TOUCHING IT WITH BARE HANDS.



Press the hot water icon once.




Begin hot water dispensing.

To dispense another cup of hot water, repeat this operation.

## LATTE MACCHIATO


Fill the milk container



Select the product and press the corresponding icon on the display: once for 1 cup and twice for 2 cups.



The machine begins grinding the quantity of coffee entered.




When the coffee finishes grinding, the machine will automatically dispense the programmed quantity of hot milk.



Once milk has been dispensed, the machine automatically prepares the coffee.



After this, the machine allows you to dispense more milk if you wish. This option remains active for approximately 2 seconds. To activate, press the "more milk" button.



The "milk rinsing" icon will flash once the machine is done dispensing in order to clean the milk circuit. Press the "milk rinsing" icon to clean the internal milk circuit.

If the user wishes to continue preparing other drinks the machine will keep the “milk rinsing” signal active.


After 20 minutes of inactivity, the machine requires the user to perform a rinsing cycle as described in Step 7. If the machine is turned off immediately after dispensing a milk product, the next time the machine is turned on it will require the user to perform a rinsing cycle.

Note: Before performing the “milk rinsing” function, make sure of the following:

1. an adequate sized container is placed under the brew unit.
2. the milk container with the cappuccinatore is filled with fresh drinking water and inserted in the machine.
3. the water tank is full of fresh water.




After 14 days from the first dispensing of a milk-based beverage, the message “milk cleaning” is displayed; it is advisable to clean the milk circuits as shown on page 28. After another 7 days, the machine comes to a halt and the milk circuits must be cleaned.



Remove the milk container from the machine; if it still contains milk, put it back in the refrigerator for later use and substitute the additional container. Rinse the container and fill with fresh water, place it in the machine and press the “start rinsing” button.



While the machine is rinsing the user cannot interrupt the cycle, but must wait until the cycle is completed. Once completed the machine returns to the main menu.




Remove the container, rinse and dry.


**THIS PROCEDURE MUST BE PERFORMED FOR ALL MILK PRODUCTS!**

## DISPENSING HOT MILK

Fill the milk container



Press the hot milk icon once.




The hot milk is dispensed.

To dispense another cup of milk, repeat this operation. When the “milk rinsing” symbol flashes, clean the milk circuits as described for latte macchiato (see page 12, Step 6).




## ESPRESSO MACCHIATO

Fill the milk container



Press the icon once for 1 cup and twice for 2 cups.



The machine begins grinding the quantity of coffee entered.



Espresso macchiato begins brewing.



Once the coffee has been brewed, the machine automatically prepares the hot milk.




To dispense more milk, press the "more milk" icon.

When the "milk rinsing" symbol flashes, clean the milk circuits as described for latte macchiato (see page 12, Step 6).

## CAPPUCCINO

Fill the milk container



Press the icon once for 1 cup and twice for 2 cups.




The machine begins grinding the quantity of coffee entered.



When the coffee finishes grinding, the machine will dispense the programmed quantity of hot milk.



Once milk has been dispensed, the machine automatically prepares the coffee.




After this, the machine allows you to dispense more milk if you wish. This option remains active for approximately 2 seconds. To activate it, press the "more milk" button.

When the "milk rinsing" symbol flashes, clean the milk circuits as described for latte macchiato (see page 12, Step 6).


## BEVERAGE PROGRAMMING MENU

Each beverage can be programmed according to your individual taste. Customization is shown on the display with the addition of an asterisk.



Once a beverage has been customized it will only dispense that type of beverage. To change or modify the beverage a new customization must be done.

To program the desired beverage:




Hold down the beverage button for two seconds

or




Press the button "my coffee" and within two seconds, press the beverage button

## ESPRESSO / COFFEE / LONG COFFEE PROGRAM




Go to the menu of the beverage to be customized (see "beverage programming menu" chapter)

In this menu you can:



Selecting a different quantity of coffee changes the aroma of the beverage.



Pressing **go!** allows the machine to brew coffee.

After pressing the **go!** button, you must finish the brew cycle.



The machine automatically starts and finishes brewing the coffee, according to the standard settings.




To brew an amount of coffee greater than that preset by the manufacturer, press "custom coffee amount" before the end of the brew cycle in progress. When the quantity is reached, press "stop coffee dispensing".

The brew cycle may be interrupted only by pressing "stop coffee dispensing". If the button is not pressed, the coffee can overflow in the cup.



Once the brew cycle finishes, press "save settings" within five seconds.

If the "save settings" button is not pressed the machine returns to the main menu and the customized settings will not be saved.



The display shows the confirmation of the memorized settings, and the machine automatically returns to the main menu.


## PROGRAMMING MILK BEVERAGES


Fill the milk tank



Go to the menu of the beverage to be customized (see "beverage programming menu" chapter on page 15).


In this menu you can:





After pressing the **go!** button, you must finish the dispense cycle.

Pressing **go!** makes the machine prepare to dispense the beverage.



The machine automatically starts and finishes dispensing the milk, according to the standard settings.



The dispensing cycle may be interrupted **only** by pressing "stop milk dispensing". If the button is not pressed, the milk may overflow.

To dispense an amount of milk greater than that preset by the manufacturer, press "custom milk amount" before the end of the dispensing cycle in progress. When the quantity is reached, press "stop milk dispensing".



The machine automatically starts and finishes brewing the coffee, according to the standard settings.



The brew cycle may be interrupted **only** by pressing "stop coffee dispensing". If the button is not pressed, the coffee may overflow.

To brew an amount of coffee greater than that preset by the manufacturer, press "custom coffee amount" before the end of the brew cycle in progress. When the desired quantity is reached, press "stop coffee dispensing".




Once the brew cycle finishes, press "save settings" within five seconds.

If the "save settings" button is not pressed the machine returns to the main menu and the customized settings will not be saved.



The display shows the confirmation of the saved settings, and the machine automatically returns to the main menu.

Some of the machine's functions can be programmed to customize operations according to your own requirements.



Press the "programming menu" button.


The programming menu will access:

Programming the machine operations (see page 18)

Special functions (see page 37)

Maintenance (cleaning the machine) (see page 27)

Activate standby



Exit

In depth product programming (see page 22)

Extra functions (see page 24)


- Current date and time
- Standby timer
- Times to turn on/turn off over the span of a day (see page 33)

After having set each of the following menus, press

- "go back" to return to the previous screen
- "restore standard values" to restore the initial values
- "save settings" to save the settings
- "back to menu" to return to the main menu


## MACHINE SETTINGS

When the machine settings are selected the following screen appears. Here you can:



## “LANGUAGE” MENU

For changing the language of the display.




This function was described at the beginning of the manual.

This setting is of fundamental importance for correctly adjusting the parameters of the machine according to the country where the machine is used.

Press to display the next page.

## “CUP ILLUMINATION” MENU

To select this function, press the “cup illumination” button and the following message will appear on the display:




In this menu you can:

This function allows you to activate/deactivate the cup illumination.

## “AQUA PRIMA FILTER” MENU

The “Aqua Prima” filter purifies water and allows you to taste all the aroma of the coffee.



In this menu you can:

proceed with activating (cleaning) the filter. After activation the “inserted” option is activated.

set the machine to operate without the “Aqua Prima” filter.


set the machine to operate with the “Aqua Prima” filter.

### Note:


- Press “activate filter” each time a new “Aqua Prima” filter is installed.
- Press “not inserted” when an “Aqua Prima” filter is not used.
- Press “inserted” when an “Aqua Prima” filter is used. This function operates even after pressing the “activate filter” button.

**“WATER HARDNESS” MENU**

To adjust the level of water hardness, shown on a scale of 1 to 4. The machine is preset at a hardness value of 3.




Immerse the water hardness strip included in the welcome pack for one second in water.



Check the value.

Press the "water hardness" button.




The test can be used only for one measurement.

Set the water hardness on the machine by pressing + or -

**“RINSE” MENU**

To clean the internal tubes in order to guarantee that the beverages are dispensed only with fresh water.




Note: This rinse cycle is performed every time the machine is turned on when it is cool.

deactivate the rinse cycle.

activate the rinse cycle.


## “CUP WARMING PLATE” MENU

To activate the cup warming plate on the upper part of the machine.




## “ACOUSTIC TONES AND ALARMS” MENU

To activate/deactivate the machine’s acoustic tones. Pressing the button does not immediately change the status.



## “DISPLAY” MENU


To set the correct brightness of the display colors, press the “display” button.






## BEVERAGE SETTINGS

To adjust the general brew parameters of the various beverages containing coffee, press the “beverage settings” button on the main menu.




For every single product, you can adjust:



The current programming status is indicated according to each parameter.


## ADJUSTMENT OF THE COFFEE BREW TEMPERATURE

To set the temperature for preparing coffee, press the “temperature” button and select the desired temperature.




## “AROMA” ADJUSTMENT FOR COFFEE BREWING

To set the “Aroma” function, that is to say the quantity of coffee to be ground, and to set the use of pre-ground coffee. You can have your beverage with the quantity of coffee you desire or you can choose to prepare it with decaffeinated coffee by using the “preground” function.



## “PREBREWING” ADJUSTMENT (ONLY COFFEE BEVERAGES)

To set the prebrewing function. The coffee is slightly dampened before brewing, bringing out the full aroma of the coffee and extracting the best flavor.



## ADDITIONAL FUNCTIONS

There are some additional functions of the machine. Pressing the “extras” button allows you to access the menu and the following message will appear on the display.

**In this menu you can:**

access the menu where some of the most famous recipes in the world are kept.

view the quantities of every type of product brewed.

activate the “demo” function to show the machine’s main functions.

## “COFFEE IN THE WORLD” FUNCTION

This function allows the user to prepare coffee according to the most famous recipes in the world.



**In this menu you can:**

prepare a typical American coffee.

prepare a true Italian ristretto.

prepare a typical Italian espresso.


prepare a typical North European coffee.

prepare a typical French/Swiss coffee.

prepare a flavorful latte macchiato without the fear of not being able to sleep.

prepare a coffee for a day full of energy.

If, for example, you want to taste a typical American coffee, you must press the “American coffee” button. In this case, the following message appears in the display.



the position of the SBS knob is shown with the best cup size to use

Pressing the **go!** button starts the brewing process.

After brewing the desired beverage, it can be saved on one of the icons of the main menu.




return to the recipe preparation menu

save the beverage

To save the beverage you just made, the display shows the icon that allows this function.

This message remains active for approximately 5 seconds and then returns to the main message.



The beverages in the “Coffee in the World” function, if saved, will be associated with the following buttons, and accompanied by an asterisk:

- |                        |                      |
|------------------------|----------------------|
| • ristretto:           | espresso (small cup) |
| • Italian espresso:    | espresso (small cup) |
| • coffee:              | coffee (medium cup)  |
| • café crème:          | coffee (medium cup)  |
| • American coffee:     | long coffee (glass)  |
| • good morning coffee: | espresso (small cup) |
| • good night milk:     | latte macchiato      |

You can associate only one beverage with a single icon. The original settings can be restored using the “Beverage Settings” menu.

## “DEMO” MODE

This function shows the machine’s potential.


Note: When this function is activated, the machine is in stand-by and all the functions are disabled. The “demo” mode is saved even when the machine is turned off by the main switch. The next time the machine is turned on, the machine will still be in the “demo” mode.

Pressing the demo button on the display shows:



This is the way the “demo” mode operation begins. The messages that follow illustrate the machine’s functionality.

To exit this mode, press anywhere on the display.



continue the tour

exit and activate the machine’s normal functions

## PRODUCT COUNTER FUNCTION

This function shows how many products have been prepared for every single type of beverage.




product counters	
hot milk	0
latte macchiato	1
cappuccino	0
espresso macchiato	0
hot water	0
coffee long	15
coffee	0
espresso	0

go back . . . back to menu

## MAINTENANCE

To clean/maintain all of the machine's internal circuits, press the "maintenance" button on the main menu.

**In this menu you can:**



The screenshot shows a 'maintenance' menu with the following options and callouts:

- lock display**: lock the Touch Screen (to preform cleaning of the display).
- milk cleaning cycle**: begin washing the milk circuits.
- milk rinsing cycle**: begin rinsing the milk circuits.
- coffee cleaning cycle**: begin the wash cycle of the brew group.
- descaling cycle**: perform the descaling cycle.

At the bottom of the menu are two buttons: 'go back' and 'back to menu'.

### MILK CIRCUIT RINSE CYCLE

To rinse the machine's internal circuits used for preparing milk.


This short cycle must be performed after 20 minutes from the last dispensing of a beverage with milk.

If the rinsing cycle is not performed, the machine comes to a halt and does not allow the dispensing of beverages.

Before performing this function make sure that:

1. a large enough container is positioned under the spout.
2. the milk container has been adequately cleaned of all milk residue and contains fresh drinking water.
3. the water tank contains a sufficient quantity of water.

Press the "milk rinsing cycle" button and then "start rinsing" to start the milk circuit rinse cycle.



The diagram illustrates the process in three stages:

- A hand selects the 'milk rinsing cycle' button on the touch screen.
- A hand selects the 'start rinsing' button on the touch screen.
- The screen displays 'rinsing milk department - please wait' and 'rinsing...'. Below the screen, it says: 'Wait for the cycle to finish. The machine will return to the main menu.'

On the right, a photograph shows a hand pointing to the 'milk rinsing cycle' button on the physical control panel, with a red arrow indicating the button's location. Below the photo, it says: 'Remove the container, rinse and dry.'

## MILK CIRCUIT WASH CYCLE


To rinse the machine's internal circuits used for preparing milk.

After 14 days from the first dispensing of a beverage with milk, the “milk cleaning” button starts flashing (see page 13). Press the button and refer to instructions at point 2. This cycle must be performed after 21 days. Refer to the instructions at point 3.

Before performing this function make sure that:

1. a large enough container is at hand.
2. the milk container has been adequately cleaned of all milk residue.
3. the water tank contains a sufficient quantity of water.


**THE WASH CYCLE CANNOT BE INTERRUPTED. A PERSON MUST BE PRESENT DURING THE OPERATION. USE ONLY AND EXCLUSIVELY THE PROVIDED DETERGENT.**




Select the function by pressing the “milk cleaning cycle” button.




Position the milk container under the water spout.



Press the “start hot water” button to dispense hot water in the container.



Wait...




When the container is filled the above message will appear.




Insert the detergent tablet into the container.




Open the compartment and insert the container with the detergent into the machine.



Close the compartment. Press the “ok” button.




Wait...  
Place a container beneath the hot water spout.



Press the "start" button.




Wait for the wash cycle to finish.




When the wash cycle has finished the above message will appear.



Remove the milk container.



Rinse the container and fill it with fresh water.



Insert the container and press the "start" button.




Wait...




When the rinse cycle has finished the above message will appear.



Remove the milk container.



Rinse the container and fill it with fresh water.





### COFFEE CIRCUIT CLEANING CYCLE (BREW GROUP WASH CYCLE)

To clean the machine's internal circuit used for brewing coffee.

We recommend using this washing cycle on a monthly basis.


Note: before performing this function make sure that:

1. a large enough container is positioned under the spout.
2. the appropriate tablet for cleaning the brew group has been inserted.
3. the water tank contains a sufficient quantity of water.

**THE WASH CYCLE CANNOT BE INTERRUPTED.  
A PERSON MUST BE PRESENT DURING THE OPERATION.**



Press the "coffee cleaning cycle" button and then "start cleaning" to start the wash cycle.




Wait for the cycle to finish. The machine will return to the main menu.

### BLOCK DISPLAY

To clean the display. The touch screen display can be cleaned with a soft dampened cloth or with the appropriate detergents for cleaning displays sold on the market.

**SOLVENTS, ALCOHOL, HARSH DETERGENTS AND/OR SHARP OBJECTS THAT CAN DAMAGE THE DISPLAY MUST NOT BE USED.**

Press the "lock display" button



To reactivate the display, press "unlock" on the lower right-hand corner and then (within two seconds) "unlock" in the upper left-hand corner (this button appears only after having pressed the previous button).

## DESCALING

To perform the automatic descaling cycle.

Descaling is necessary every 2-3 months, depending on the volume of use and hardness of the local water supply.


The machine must be turned on and will automatically manage the distribution of the descaling agent.

**A PERSON MUST BE PRESENT DURING THE OPERATION.**

**WARNING! NEVER USE VINEGAR AS A DESCALER.**

Saeco descaler is recommended, however you can use a non-toxic and/or non-harmful descaling product for coffee machines, commonly available online or in coffeeshops. The solution used must be disposed of according to the manufacturer's instructions and/or according to the regulations enforced in the country of use.

Note: Before beginning the descaling cycle make sure that:


1. a large enough container is positioned under the water spout and the brew head.
2. **THE "AQUA PRIMA" FILTER HAS BEEN REMOVED.**
3. the water tank has been filled with the descaling solution up to the level indicated with an .

Pause descaling.

The descaling and/or rinsing can be paused and then restarted. When descaling is interrupted the machine will warn the user that it must be turned off.

**WARNING! DESCALING MUST BE COMPLETED WITHIN 24 HOURS FROM ITS INTERRUPTION.**

The next time the machine is turned on, the machine will warn the user that the descaling and/or rinse process must be completed.




The machine indicates to the user the need to complete the descaling through the message on the main menu. This does not block the machine's operation.

The number under the message indicates the number of dispensed beverages before the machine needs to be descaled.

30 beverages before descaling, the button will begin to flash. When the number reaches zero, the machine must be descaled.


Pressing the descaling button accesses the descaling menu.




When in the descaling menu, the message "fill the water tank with descaling solution" appears on the display.

Perform the descaling cycle by pressing "start descaling" as shown.

In order to run a descaling cycle before the machine indicates the necessity to do so, press the button "descaling cycle" and then "start descaling" to start the descaling cycle.




The machine begins to dispense the descaling solution through the hot water spout. The dispensing occurs at preestablished intervals, in order to allow the solution to be more effective.




When the solution is finished the following message appears on the display:



Remove the water tank and rinse with fresh drinking water to eliminate traces of descaling solution. Then, refill with fresh drinking water and reinsert water tank.



Rinse the machine circuits by pressing "start rinsing".



The machine performs the rinse cycle. At the end of the rinse cycle you are requested to fill the tank with fresh drinking water. Before refilling the tank, reinsert the Aqua Prima filter if desired.




Put a container under the water spout. When the water tank is inserted the machine automatically proceeds to priming the water circuit. If this operation is not successful, consult "manually priming the circuit" (see page 6)

## CLOCK SETTINGS

To adjust the current date and time, the timer for stand-by (energy savings) and the times for automatically turning on and turning off the machine. Press the "timer" button on the main menu.

In this menu you can:

set the parameters for stand-by after the last brew.



set  
- the current time  
- the current date  
- the view format  
(24 hour – AM/PM)

set the intervals for turning the machine on and off (three intervals that can be activated separately).

## TIME SETTING


To set all the parameters relating to the clock and calendar. Important: To correctly program the times for turning the machine on and off, press the "timer settings" button.



modify the settings related to the current time and the day of the current week.

modify the settings relating to viewing the time (in 24 hour or am/pm format).

In this menu you can:



view the current time setting.

view the current day of the week setting.


view the current time format setting.

## Current time/day of the week

To set the day of the week and the current time on the machine. Press the "time/weekday" button.



In this menu you can:




Adjust the hour by pressing + or -

Adjust the minutes pressing + or -

Adjust the day pressing ◀ or ▶


## Time format

To set the time view mode. This setting adjusts all clock functions to either “am/pm” or “24 hour” formats. To set the time view mode, press the “time format” button. The modification is immediately applied and in small writing appears ‘am/pm’ or “24 hour”.



## AUTOMATIC TIMER SETTINGS

With this function you can turn on (activate) and turn off (energy savings) the machine at the desired times. Remember that the machine manages this function only if it is turned on.





To correctly program the automatic timer settings, you must:

- set the individual intervals for turning on and turning off the machine.
- choose on which days to apply these auto on/off intervals.

It is recommended to not overlap intervals for turning on the machine.

### Setting an interval for turning on the machine


In order to program an interval for turning on the machine, press the button for the interval that you wish to set.



Adjust the hour to turn on by pressing + or -

Adjust the minutes by pressing + or -

To save the adjusted settings and go to the next screen



Adjust the hour to turn off by pressing + or -

Adjust the minutes by pressing + or -


To save the adjusted setting

### For every day, choose the intervals for turning on

Arrow through the days of the week, and for each day, select the automatic timer intervals you wish to activate.



Interval not active for the selected day



Interval active for the selected day

Select the day by pressing < or >


To save the settings

Each day you can select various intervals.

## ENERGY SAVING SETTINGS


To set after what duration of time, from the last dispensed beverage, the machine will go into stand-by mode.

The default setting is "after 3 hours".



Select the desired time to activate stand-by.

When the selected duration of time has passed, the display reads "stand-by".



To activate the machine, press "go". After having performed the function diagnostics and the heating up phase, the machine is once again ready for use.

## SPECIAL

This menu allows you to access special functions present on the machine. Press the "specials" button on the main menu.




## FACTORY SETTINGS

The function for restoring all the factory settings is contained in this menu. This function is particularly important for restoring the original settings. Press the "factory settings" button.



If "yes" is selected, a subsequent confirmation by inverted switch buttons is requested to be sure that you want to perform the reset.

**ALL THE CUSTOM SETTINGS WILL BE LOST AND CANNOT BE RECOVERED. AFTER RESTORING FACTORY SETTINGS, YOU MUST, IF DESIRED, REPROGRAM ALL THE MACHINE'S FUNCTIONS.**



Selecting "yes" restores the settings.

On the display, the message "All parameters are reseted" appears for two seconds.

After this period, the machine returns to the main display.



## GENERAL MACHINE CLEANING

The cleaning described below must be performed once a week.

Note: Always use fresh water. If water is in the machine for several days, empty tank and refill it.

**WARNING!** Do not immerse the machine in water.

Clean the cappuccinatore as shown in the corresponding section on page 40.



Turn the machine off and unplug the cord.



Clean the tank and the cover.



Remove the drip tray, empty and hand wash.



Remove the dregsdrawer, empty and wash.



With the brush, clean the pre-ground coffee compartment.



Clean the cappuccinatore as shown in the corresponding section on page 40.



Remove the liquid tray, empty and hand wash.



Clean the display (see page 30).

## CLEANING THE BREW GROUP

The brew group must be cleaned at least once a week.

Wash the brew group with warm water.

**WARNING!** Do not wash the brew group with detergents that can compromise its correct operation. Do not wash in the dishwasher.



Press to open the service door.



Press the PUSH button to remove the brew group.




Wash any coffee residues from the brew group.



Wash the upper filter with running water.



Make sure the group is ready to be put back in. The two references must align.



Make sure that the components are in the correct position.



Lubricate the guides and the o-ring of the brew group, only with the supplied lubricant.



Reinsert the brew group by pressing the PUSH button and sliding into place.



Close the service door and insert the brew drawer.


## GRINDER MAINTENANCE

After approximately 2000 grinding cycles, the grinder needs a slight adjustment to ensure it is running in peak condition.

### WARNING!

This operation should be carried out carefully and by an experienced user. Empty the coffee bean hopper. The screw could fall into the grinder; if it happens remove it before restarting the machine.


The snap is signalled by a message on the coffee bean hopper; refer to these messages when this adjustment is performed. Be sure to empty the coffee bean hopper before starting. Note: the screw could call into the grinder; if that happens, be sure to remove it before continuing the cleaning.



1  
Unscrew the screw that holds the service door closed.



2  
Remove screws and service door.



3  
Adjust until it clicks.

Then reposition the door and attach it with the previously removed screw.


## MILK CONTAINER CLEANING.

To guarantee that the parts that come into contact with milk are perfectly clean and to optimize the performance of your Primea Cappuccino, we recommend cleaning the appropriate container under running water before dispensing milk-based beverages. To simplify this operation, the machine is equipped with a special accessory (cleaning pin) that eliminates any milk residue in the cappuccinatore (see fig. 3).

This operation must be performed **between two dispensing cycles** of milk-based beverages (regardless of when the last circuit rinse cycle was performed, see manual), while it is not necessary in case of consecutive dispensing.



1  
Rinse the container and the cleaning pin under running water.



3  
**Proceed with caution!**  
Insert the cleaning pin all the way into the indicated hole.

## GUIDE MESSAGE THAT APPEARS

## HOW TO REMOVE THE MESSAGE

(switch the machine off and then on again to solve the problem)

Turn off and after 30 minutes turn the machine on again to restore normal operation.

(call customer service center.)

Problem that requires the intervention of the customer service center.

(insert drip tray)

Insert drip tray under the brew group.

(close coffee container)

Close the coffee bean hopper cover to be able to brew any product.

(add ground coffee)

This message guides the user when, in the customized product programming, the use of this type of coffee has been chosen.

(insert the brew unit)

Insert the brew group in its place.

(insert dreg drawer)

Insert the dregsdrawer

(empty dreg drawer)

Remove the dregsdrawer and empty the grounds in an appropriate container.

**Note: The dregsdrawer must be emptied only when the machine requires it and when the machine is turned on.**

**Emptying the drawer with the machine turned off does not allow the machine to register that it has been emptied.**

(close the door)

To be able to make the machine functional, the side door must be closed.

(refill water tank)

The tank must be removed and refilled with fresh drinking water.

(empty drip tray)

Open the side door and empty the drip tray under the brew group)

(insert the milk container)

Insert the milk container in the appropriate compartment

(prime the circuit)

Press on the display in order to proceed with manually priming the water circuit. The machine performs an automatic attempt to prime the circuit. If this attempt does not perform correctly you must proceed with these instructions.

(circuit priming failure)

Contact the customer service center (toll free number) to request assistance on how to resolve the problem.

(the descaling cycle has not been completed correctly)

Repeat the operation as described in the appropriate section.

(rinse milk)

see page 13 and 27.

(milk cleaning)

see page 13 and 28.

## GUIDE MESSAGE THAT APPEARS

(replace the Aqua Prima filter)

## HOW TO REMOVE THE MESSAGE

The Aqua Prima filter must be replaced in the following cases:

1. 60 liters of water has been dispensed;
2. 90 days have passed since its installation;
3. 20 days have passed and the machine has not been used.

Note: this message appears only when "inserted" has been selected in the water filter function (See page 19).

(the cleaning cycle has not been completed correctly)

Repeat the operation as described in the appropriate section.

(insert the cappuccinatore)

Insert the cappuccinatore in the milk container. Without the cappuccinatore no product containing milk can be dispensed.

(rinse the milk tank)

The user must wash the milk tank after it has been used.

(descale the machine)

A descaling cycle must be performed on the machine's internal circuits.

(energy saving)

Press the "start" button

## TECHNICAL DATA

<b>Nominal voltage</b>	See label on the appliance
<b>Power rating</b>	See label on the appliance
<b>Power supply</b>	See label on the appliance
<b>Shell material</b>	Plastic
<b>Size (w x h x d)</b>	355 x 380 x 460 mm - 13.8" x 15.4" x 16.9"
<b>Weight</b>	14 Kg - 30.9 lbs
<b>Cable length</b>	1200 mm - 42.2"
<b>Control panel</b>	(Digital) Front
<b>Water tank</b>	2 liters - 68 oz. / Removeable
<b>Milk Tank</b>	ca. 0.400 liters - 12.5 oz. / Removeable
<b>Coffee Bean Hopper Capacity</b>	350 grams - 8.9 oz. / of coffee beans
<b>Pump pressure</b>	15 bar
<b>Boiler</b>	Two in stainless steel
<b>Coffee grinder</b>	With ceramic grinders
<b>Pressure safety device</b>	Boiler pressure safety valve
<b>Temperature safety device</b>	Boiler thermostats and thermal fuses

Subject to engineering and manufacturing changes due to technological developments.

The machine conforms to the European Directive 89/336/EEC (Italian Legislative Decree 476 dated 04/12/92) concerning electromagnetic compatibility.

# SOS

## IN CASE OF EMERGENCY

Immediately unplug the cord from the outlet.

## ONLY USE THE APPLIANCE

- Indoors.
- For preparing coffee, hot water and for foaming milk.
- For domestic use.
- By adults in non altered psycho-physical conditions.

## PRECAUTIONS FOR THE USE OF THE MACHINE

- Do not use the machine for purposes other than those indicated above, in order to avoid danger.
- Do not introduce any substances other than those indicated in the instruction manual.
- During the normal filling of any reservoirs, all nearby reservoirs must be closed.
- Fill the water tank only with fresh drinking water: Hot water and/or any other liquid may damage the machine.
- Do not use water with carbon dioxide added.
- Do not put fingers or any material other than coffee beans in the coffee grinder.
- Before manipulating the coffee grinder, turn of the machine's main switch and unplug the cord.
- Do not put instant coffee or whole bean coffee in the ground coffee container.
- To operate the machine with the touch screen, use only your fingers.

## CONNECTION TO ELECTRICAL POWER

The connection to the electrical network must be carried out in accordance with the safety regulations in force in the user's country.

The machine must be connected to a socket which is:


- compatible with the type of plug installed on the machine;
- suitably sized to comply with the ratings shown on the machine identification plate.
- effectively grounded.

The power cord must not:

- come into contact with any type of liquid: danger of electric shocks and/or fire;
- be crushed and/or come in contact with sharp surfaces;
- be used to move the machine;
- be used if damaged;
- be handled with damp or wet hands;
- be wound in a coil when the machine is being operated.
- be tampered with.

## INSTALLATION

- Choose a solid, stationary flat surface (no more than 2° of inclination).
- Do not install the machine in areas where water could be sprayed.
- Optimal operational temperature: 10°C - 40°C / 50-104 degrees Fahrenheit
- maximum humidity: 90%.
- The machine should be installed in an adequately lit, ventilated, hygienic location and the electric socket should be within easy reach.
- Do not place on heated surfaces!
- Install it at least 10 cm / 4" from the walls and cooking surfaces.
- Do not use in places where the temperature may drop to a level equal to and/or lower than 0°C / 32 degrees Fahrenheit. If the machine has been exposed to such conditions notify the customer service center, who will have to carry out a safety check.
- Do not use the machine near inflammable and/or explosive substances.
- The machine must not be used in an explosive or volatile atmosphere or where there is a high concentration of dust or oily substances suspended in the air.
- Do not install the machine on top of other appliances.





## DANGERS

- The appliance must not be used by children and persons who have not been informed of its operation.
- The appliance is dangerous to children. When left unattended, unplug from the electrical outlet.
- Keep the coffee machine packaging out of the reach of children.
- Never direct the jet of hot water and/or steam towards yourself or others. Danger of scalding.
- Do not insert objects through the appliance's openings. (Danger! Electrical Current!).
- Do not pull out the plug by yanking on the power cord or touching it with wet hands.
- Warning. Danger of burning when in contact with hot water, steam and the hot water spout.



## FAILURES

- Do not use the appliance if a failure has been verified or suspected, for example after being dropped.
- Any repairs must be performed by an authorized customer service center.
- Do not use the appliance with a defective power cord. The manufacturer or its customer service center will have to replace the power cable if damaged. (Caution! Electrical Current!).
- Turn off the appliance before opening the service door. Danger of burns!



## CLEANING / DESCALING

- For cleaning the milk and coffee circuits use only recommended detergents provided with the machine. These detergents must not be used for other purposes.
- Before cleaning the machine, the main switch must be turned to OFF (0), unplugged from the socket and cooled down.
- Keep the appliance from coming into contact with splashes of water or immersing in water.
- Do not dry the machine's parts in conventional or microwave ovens.
- The machine and its components must be cleaned and washed after the machine has not been used for a certain period.



## REPLACEMENT PARTS

For safety reasons, use only original replacement parts and original accessories.



## WASTE DISPOSAL

This product complies with EU Directive 2002/96/EC.

The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment.

By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

## FIRE SAFETY

In case of fire, use Carbon Dioxide extinguishers (CO<sub>2</sub>).  
Do not use water or dry-powder extinguishers.



